KitchenAid® COOKTOP PARTS

30" FREE STANDING
ELECTRIC OVEN
CONVECTION

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Literaturre Parts
	9763461	Installation Instructiions
		Use & Care Guide
	W10109440	English
	w10048890	French
		Tech Sheet
	9762786	English
	W10065220	French
	9757680	Anti−Tip Instruct.
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips (French)
	9763467	Guide, Easy Set
2	9761801	Central, Appliance
3	9761784	Bracket, Mounting
4		Cooktop
	W10110274	White
	W10110276	Black
6		Trim−CkTop, SI
	W10110680	White LH
	W10110682	Black LH
	W10110679	S.Steel LH
	W10110685	White RH
	W10110687	Black RH
	W10110684	S.Steel RH

Illus. No.	Part No.	DESCRIPTION
7	W10076020	Gasket, Cooktop
9		Support
	9757686	L.Hand
	9757687	R.Hand
10	9756821	Support, Wiring
11	4449809	Screw (2)
12		Element, Surface
	8203525	1800/1000W
	8523696	1800W RR
	4453909	2500/1200W (2)
13	9761423	Bracket, Front Support
14	9761577	Cover, Backsplash Rear
15		Backsplash
	W10109750	Black
	W10109740	White
	W10109770	Nickel Plated
		Gasket
	9763483BL	Black
	9763483GY	Gray

Illus. No.	Part No.	DESCRIPTION
16	9759944	Thrmstat, 60c SPST
17	9758799	Bracket, Ind. Lamp
18	3196160	Screw (2)
19	9759094	Spring, Locator
20	9761783	Bracket, Rear Sprt
21		Rail, Element (2)
	9763517	Side (3)
	9757825	Center (1)
22	246119	Screw
23	9761724	Cover, Cktp Rear
24	8523739	Indicator Lamp, Hot Surface
25	3196537	Screw
26	9762768	Clip, Retainer
27		Glass, Backsplash
	9761749BL	Black
	9761749WH	White
28	W10050270	Grommet (19mm)
29	W10050280	Grommet (38mm)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	9761551WH	White
	9761551BL	Black
	9761551NP	Nickel Plated
2	9761566	Switch, Membrane (Touchsensor Glas)
3	9761799	Control, Interface
4	W10105370	Shield, Console
5	3196068	Lens, Ind. (2)
6	9761745	Brkt, Touchsensor
7	3196160	Screw
8	W10109430	Gasket
9		Knob
		(RF)
	9761780WH	White
	9761780BL	Black
	9761780NP	Nickel Plated
		(LF,RR,LR)
	9762764WH	White
	9762764BL	Black
	9762764NP	Nickel Plated
11		Switch, Infinite
	9763761	RF
	9763762	LF,RR,LR
12	9757778	Bushing
14	3196537	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)
	W10109570	White
	W10109540	Black
	W10109560	S.Steel (Left Hand)
	W10109520	White
	W10109490	Black
	W10109510	S.Steel
2	3400832	Screw
3		Hinge Receiver
	4455605	Left Hand
	4455606	Right Hand
4	9760749	Bumper, Door
5	9757461	Bracket,Side Panel
6	9757811	Brace, Side Panel
7	8303099	Top Chassis
8	4449809	Screw
9	4452158	Tube, Vent
10	W10067870	Lens, Light
11	W10009930	Oven Light Assy
12	4452166	Bulb, Light
14	9760756	Frame, Front
15	W10074200	Gasket, Door
17	4452152	Bracket, Mounting
18	9757685	Guide,Side Pnl (2)
19	4451478	Support, Insulation
20		Body, Side
	9760723PB	Black
	9760723PW	White
21	3196537	Screw
22	9760888	Latch, Motorized
23	341196	Thermostat SPST (205)
24	9759890	Clip, Side Panel
25	4455641	Side, Chassis (R.H. & L.H.)
26	9759761	Back, Chassis
27		Liner, Oven (Not serviceable)
28	9759945	Cover, Rear Standoff
29	4455636	Sensor
30	9756454	Bracket, GOC
31	W10083460	Slide. GOC
32	3196160	Screw
34	4449743	Screw
35	3196176	Screw
36	4449040	Screw
37	9759242	Thermostat (TOD) Manager, 130c (Temp.) SPST
38	4449154	Screw
43	9759713	Base, Chassis
49	4448933	Retainer, Gasket
50	9758583	Cover, Back
54		Vent, Bottom Upper
	9756481WH	White
	9756481BL	Black
	9756481SS	S.Steel
55		Trim, Btm Vent
	W10104910	White
	W10104890	Black
	W10104870	S.Steel

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

9756817	Insulation, Wrap
9756470	Insulation, Back

DOOR AND DRAWER PARTS

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
1		Nameplate
	9763444BL	Black
	9763444WH	White
	9763444SS	S.Steel
2	3400832	Screw
3	3400805	Screw
4	4457132	Retainer, Glass
5		Glass, Door Front
	9762766BL	Black
	9762766WH	White
	9762766SS	S.Steel
6	W10045140	Cover, Terminal
7	3196176	Screw
8		Handle, Door
	8303774BL	Black
	8303774WH	White
	8303774SS	S.Steel
9	9759230	Bracket, Central
10		Hinge, Door
	9760579	R.Side (Orange)
	9760580	L.Side (Orange)
11	9761935	Foot, Rear
12	9759229	Bracket, Side
13	8274149	Sensor
14	9760775	Element, Warming
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	9759225	Glass, Inner (2)
18	4451722	Insulation, Door
19	9759413	Liner, Door
20	9757805	Drawer Assy
21	3196037	Foot, Front
22	9763456	Panel, Drawer
23	9758676	Support, Element
24		Front, Drawer
	9761747WH	White
	9761747BL	Black
	9761747SS	S.Steel
25		Bracket, Handle
	9763497	R.Hand
	9763496	L.Hand
26		Handle, Drawer
	9761573WH	White
	9761573BL	Black
	9761573SS	S.Steel
27	8533988	Screw
28	4449809	Screw
29		Side, Base
	9759953	R.Side
	9759954	L.Side
30	4449743	Screw
31	3196537	Screw
32		Guide, Roller
	W10019810	R.Hand
	W10019800	L.Hand
33	4457103	Shield, Heat Top

INTERNAL OVEN PARTS

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	9760774	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	9760768	Element, Bake
8	9755542	Probe, Meat
9	9760769	Element, Convect.
10	9756690	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	4451583	Motor, Convection
14	4452227	Nut
15	4452226	Blade, Fan
16	9755543	Jack, Meat Probe
17	9755547	Lock Washer
18	9755546	Hex Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3		Blower
	9759320	45mm
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
7	4449809	Screw
8	9759987	Box, Terminal
11	4449868	Block, Terminal
12	9759876	Cover, Term Box
14	9757829	Bracket, Transfrmr
15	9760212	Transformer
16	4449040	Screw
18	3196160	Screw
21	4455352	Bracket, Blower

OPTIONAL PARTS

For Models: YKERS807SB00, YKERS807SP00, YKERS807SS00
(Black) (Pure White) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
	261869	Cord Brown
	72032	Black
PAINT, SPRAY		
	350930	White
	261900	Citrine White
	830864	Black
ADHESIVE		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
SPLICING WIRES−−25FT. LENGTH		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
WIRING HARNESS PARTS		
	9761567	Harness, Wire (Main)
	9762909	Harness, Wire (Switch, Elec)
	9762921	Harness, Wire
	W10109280	Harness, Cktp (Elec. Sw.)
	9763481	Harness, Ground Strap
	9759922	Conduit
	9761059	Cord, Power
	9759877	Retainer, Strain Relief
	313660	Clip, Ground Wire
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4452222	Spacer, Harness
	3400015	Screw, Ground
Miscellaneous		
	814381	Hinge Pin Kit
	4448950	Screw, Install (4)
	9782676	Anit−Tip Assy